G-TONE
Owner's Manual
Acoustic Guitar Preamp

www.cherubtechnology.com

GT-6 Acoustic Guitar Preamp



1. When the output cable is **connected** to **GT-6**, it will start automatically. When the output cable is pulled out, it will shut down automatically.
2. **GT-6** has 3- band equalizer. Rotate **LOW/MIDDLE/HIGH** to adjust low/medium/high frequency. Rotate **VOL.** to adjust master volume. Rotate **REVERB/DELAY** button to adjust reverb and delay effect. Rotate **CHORUS/WIDE** button to adjust chorus and wide effect.
3. Press **PHASE** button to play/stop PHASE function.
4. Press **TUNER** button to turn on/off tuner. Output will be mute when turner is on.
5. When turn on the tuner and play any string, appears in the display, it will indicate the tuning result.

   Sharp Flat In tune
6. When the BATT. lights is on, please replace the battery as soon as possible.

GT-6 箱琴EQ系列



1、将输出线连接好后**GT-6**自动启动，输出线拔出后**GT-6**自动关闭。
2、**GT-6**有三段EQ均衡器，旋转**LOW**旋钮调节低频，**MIDDLE**旋钮调节中频，**HIGH**旋钮调节高频，**VOL.**旋钮调节总音量，**REVERB/DELAY**旋钮前半段调节混响效果，后半段调节延时效果，**CHORUS/WIDE**旋钮前半段调节合唱效果，后半段调节宽广效果。
3、按**PHASE**按键开启或关闭PHASE功能。
4、按**TUNER**按键开启或关闭校音器。当校音器打开时，输出静音。
5、校音器开启后，拨任意弦 显示窗口将显示校音状态。

   偏高 偏低 音准
6、BATT.灯亮时表示电池电量不足，请尽快更换新电池。

More Musical, More Scientific,and More for YOU!

CHERUB TECHNOLOGY CO.,LTD